

**Brass mounting screws - Antique Brass**

14922



Use these antiqued brass screws to mount UK rocker switch and electrical insert front plates.

Having extras on hand will help in case any of the supplied screws are damaged or lost during installation.

- Sold individually
- For use with UK rocker switches and electrical inserts (excludes toggle and dimmer switches)